

PFID 1010030

- This meter records a 'night rate' tariff only.
- One reading from this meter will be returned to your retailer to be recorded on your invoice.
- This information is recorded in Register 1.

Register #	Description
1	The total usage in kWh recorded on this meter since it was installed on your meter board. The current month to date usage is the difference between this number and the reading on your last power account.
54	The total load in kW on the meter at the point in time it is being read
31	The time in NZ Standard time
32	The date
33	Programme File ID
34	Programme File version
88	Test screen

The registers in the chart above are displayed by default. The meter is programmed with two alternate display lists.

Alternative 1 display – press and hold **Button 1** until AL 1 is displayed on the display screen.

This display list has information about voltage, amps and power factor that may be required by an electrician or technician. You can scroll through using **Button 1**.

Register #	Description
41	This is the voltage reading on this meter at the point in time it is being read. Voltage may vary throughout the day and from day to day. Readings between 216 – 244 are within legal tolerances.
51	For PFID 1010030 this reading will always be 0
52	The total load in kW on the meter at the point in time it is being read (same as Register 54 in normal display)
61	For PFID 1010030 this reading will always be 0
62	This is the power factor reading on this meter at the point in time it is being read
71	For PFID 1010030 this reading will always be 0
72	This is the amp reading on this meter at the point in time it is being read
81	For PFID 1010030 this reading will always be 0
82	This is the total usage in kWh recorded on this meter since it was installed on your meter board. (same as Register 1 in normal display)
40	Meter information

Alternative 2 display – press and hold **Button 1** until AI E 2 is displayed on the display screen.

This display list has ripple control information that is only relevant to technicians. Load control is operating on this meter if LC is recorded in lower right hand corner of the display screen. When load control is operating there will be no power supply to your controlled load (ie hot water). When LC1 is recorded on the display screen there is no load control operating and you should have power to your controlled load.

The meter will automatically default back to the normal display list after it has scrolled through the Alternate display list.